


B² audio

MODEL: ZERO.7R

PRODUCT ID:ZERO.7R1SD



Zero.7_R

OWNER'S MANUAL



INTRODUCTION

We thank you for purchasing our amplifiers. Your decision to be part of something different is what we strive for. Our products reflect who we are, going to the extent to deliver you our finest comes natural. Our amplifiers are engineered to accommodate a variety of applications. Whether it is SPL or SQ, the sound provided will be clean & dynamic. We refer to it as SQL audiophile products, based on optimizing every aspect of the amplifier to have the highest possible efficiency, while minimizing distortion, causing less stress on the audio reproduction and increasing the Sound Quality & output performance.

To obtain the full potential of the amplifier & to minimize failure, it is strongly recommended & necessary to upgrade the stock electrical system. Ensure the system is in accordance with the full performance of the amplifier. It is therefore essential to read through the whole manual.

For continuous news & updates feel free to visit us at

www.facebook.com/b2audio - www.youtube.com/b2audio - www.b2audio.com - www.twitter.com/b2_audio - www.instagram.com/b2_audio



Better Bass

BETTER BASS IS OUR PHILOSOPHY OF ADDING SOMETHING EXTRA. KEEP IN MIND THAT CONTINUOUS EXPOSURE TO SPL ABOVE 100 DB CAN SERIOUSLY DAMAGE YOUR HEARING. TODAY'S HIGH POWER AUTO SOUND SYSTEMS CAN EASILY PRODUCE SPL OVER 140 DB. ENJOY YOUR MUSIC WITH SENSE.

TABLE OF CONTENTS

DESIGN FEATURES	3	SPEAKER WIRING - SINGLE AMP	8
PANEL LAYOUT	4 - 5	STRAPPED CONTROL PANEL SETTING	8
INSTALLATION	6	* STRAPPED SPEAKER WIRING	8
*PREPARATIONS	6	STRAPPED CONTROL PANEL SETTING	9
*POWER CONNECTORS	6	* STRAPPING / LINKING STEPS	9
*REMOTE & RCA INPUT	6	* STRAPPING / LINKING STEPS	10
WIRING LAYOUT	7	CROSSOVER	11
		TROUBLESHOOTING	12

DESIGN FEATURES

CIRCUIT CONFIGURATION:	<i>Zero.7R</i> HI-EF CLASS D
FREQUENCY RESPONSE:	10 HZ - 250 HZ
SIGNAL TO NOISE RATIO:	> 100 DB
INPUT SENSITIVITY:	6 V - 0.2 V
CROSSOVER CIRCUIT:	24 DB / OCTAVE
LOW PASS CROSSOVER:	35 HZ - 250 HZ
SUBSONIC CROSSOVER:	10 - 50 HZ
PHASE SHIFT:	0 - 180 DEGREES
DAMPING FACTOR:	> 300
BASS BOOST FREQUENCY:	30 HZ - 90 HZ
BASS BOOST:	0 - 9 DB / 45 HZ
REMOTE CONTROL:	INCLUDED
POWER TERMINAL GAUGE:	0 GA X 3
FUSE RATING:	500A
DIMENSIONS:	11.8" X 2.52" X 25.59" / 300 MM X 64 MM X 650 MM

All features are subject to change in the continuing effort to improve the products without notice.

SPECIFICATIONS

CONTINUOUS OUTPUT POWER (RMS)

	[12 V < 1% THD]	[14.4 V < 1% THD]	[16 V < 1% THD]
POWER @ 4 Ω :	1000 W X 1	1500 W X 1*	
POWER @ 2 Ω :	2000 W X 1	3000 W X 1*	
POWER @ 1 Ω :	3800 W X 1	6000 W X 1*	6750 W X 1*

DESCRIPTION OF SPECIFICATIONS

Stable impedance load of the Zero.7R is 1 Ohm.

Operation below minimum impedance will stress the amplifier & void the warranty.

Excessive heat will also appear at a faster rate and the amplifier will go into thermal protection.

Protection can also be caused by the following

- * Speaker overload
- * Short circuit
- * Input Voltage - RCA & Power Supply


The PCB is a HI-EF Class D design. THE HI-EF circuit optimizes efficiency & improves performance even at low voltages.

Operational voltage: 10 V ~16 V. Operational voltage will also be affected by the load of the amplifier

*In order to get the full power output of the amplifier, it is crucial that your electrical system is correctly (over)dimensioned.

PANEL LAYOUT

ZERO.7R



INPUT

RCA signal input for Left & Right channel.
A minimum of 0.2 v input signal is required for correct operation.

POWER & PROTECTION INDICATOR

Power LED, blue light shows correct operation,
Protect LED, red light shows general malfunction, faulty connection or thermal protection.

GAIN (0.2V-6V)

Adjusts signal input voltage from the source to match the amplifiers input stage.
0.2 V ~ 6 V is the operational voltage.
Voltages beyond may cause damage.

SUBSONIC

Variable subsonic setting from 10 Hz to 50 Hz.
It is highly recommended to set it according to the tuning of your subwoofers to avoid unnecessary strain to your sound system.

BASS BOOST

Variable signal boost of the BASS FREQ chosen with 0 dB ~ 9 dB.

LPF (LOW PASS FILTER 35 HZ -250 HZ, 24 DB/OCT)

Adjusts the cut off point for the low pass crossover at the frequency chosen.

PHASE (0 - 180 DEGREES)

Variable phase adjustment from 0 ~ 180 degrees.

REMOTE LEVEL CONTROL PORT

Connection of external signal level control.
CAUTION, the amplifier needs to be gained in accordance with the remote to avoid excessive signal boost.

MASTER / SLAVE

Enables daisy chain (strapped mode) of 2 amplifiers.
Minimum warranted impedance is 2 ohm.
See page 8 for complete instructions on how to run the amplifiers in linked mode.


SPEAKER (SPEAKER OUTPUT)

Connects to the speaker(s) leads. Ensure polarity is correct on the speaker and connect to the corresponding output. Minimum impedance is 1 ohm.
In STRAPPED mode, minimum load is 2 ohm.
Use high quality cable of at least 12 Ga.

B² audio

PANEL LAYOUT

ZERO7R



GND (GROUND CONNECTION)

Connects to the vehicle's chassis.
Keep as short as possible (< 20" / 50 cm)
Use minimum 0 Ga cable for optimal conditions.

REM (REMOTE)

Connects to switched +12V from the headunit.

+ 12V (POWER CONNECTION)

Connects to the positive terminal of the battery.
For specified performance 0 Ga cable is required.
Fuses shall be placed within 8" / 20 cm of the battery.
The HI-EF class D design allows for higher output power, even at low voltage applications.
This sets high requirements to the battery system.
Choose batteries with high CCA ratio.

CAUTION

INSTALLATION OF THE AMPLIFIER SHALL BE DONE IN THE FOLLOWING STEPS:

1. Connect the +12V wire, keep in mind this wire has to be fused at the battery as well.
2. Ensure the ground is appropriate, then connect it to the amplifier.
3. Connect the switched remote.
4. Reattach negative wire (ground) to the battery.
5. Operation over 16V will cause the amplifier to go into protect & can void the warranty!

B² audio

INSTALLATION

INSTALLATION CONSIDERATIONS

If you choose to install the amplifier by yourself, please read the entire owner's manual carefully. Before you start your installation, please take all steps into consideration.

If in doubt, please go to www.b2audio.com for authorized distributors / dealers that will be able to configure your set up & ensure the warranty of your amplifier.

PREPARATION

Disconnect the negative (-) battery cable before mounting or making any connection. Check the battery & alternator ground (-) connection. Make sure they are properly connected/dimensioned & free of corrosion. Before selecting a mounting location for the amplifier, please take cooling & safety into consideration. Avoid areas with excessive vibration & up side down installation!

In order to avoid excessive heat from the amplifier, it is recommended to find a mounting location that allows for vertical positioning of the heatsink fins. For safety purposes, install the amplifier in a dry and well ventilated location and make sure no cables or other harness of the car is interfaced with the mounting location or will present a hazard to the car's cable, control cables, fuel lines/tanks, hydraulic lines or other components of the vehicle. Route the RCA cables away from high current wires, if possible run RCA, Power and Speaker cables individually and with a good distance from each other.

POWER CONNECTORS

12V (POWER CONNECTION)

Before mounting the amplifier, disconnect the negative (-) wire from the battery to protect any accidental damage to the amplifier or the audio system. The amplifier is equipped with triple 0 AWG power & ground terminals. It is crucial that all terminals are used with the adequate cable to ensure correct operation.

Connect the power cables to the power terminal labeled as +12V.

The amplifier is not equipped with fuses, so external fuses are required at both the battery and the amplifier.

Connect one end of the fuse holder to the power cable and the other end of the fuse holder to the positive battery terminal within 8" / 20 cm of the same cable. The same shall be done at the other end of the cable that connects to the amplifier. The fuses will protect the system and the vehicle against the possibility of a short circuit in the power cable. Make sure that the fuses and the fuse holder is according to the system requirements.

GND (GROUND CONNECTION)

Locate a secure grounding connection as close as possible to the amplifier.

Make sure the location is clean and provides a direct electrical connection to the chassis of the vehicle.

Connect one end of an equal sized cable as the positive cable to the location of ground.

It is important that the ground cable is as short as possible, but no longer than 20" / 50 cm at maximum.

Run one end of the cable to the grounding point. Run the other end of the cable to the mounting location.

Connect the ground cable to the terminals labeled as GND.

REM (REMOTE CONNECTION)

Run a remote turn on cable from the switched +12V source.

This may be a toggle switch, a relay, the source unit's remote output cable or power antenna trigger cable.

Connect the remote turn on cable to the power terminal labeled as REM.

INPUT (RCA CABLE)


Run the RCA cables away from the high current cables / speaker cables and connect to the amplifier.

Use high quality cables with a secure grounding point to avoid amplifier malfunction and / or alternator whine.

B² audio

WIRING LAYOUT

ZERO7R



We recommend to use minimum 12 Ga speaker cables to acquire the intended performance. Run the speaker cables from your speakers to the amplifier's mounting location. Ensure these are ran separately and away from high current cables and if possible the RCA cables as well. In all cases where cables are penetrating the vehicle's chassis use grommets to protect the cable.


Connect the speaker wires according to the terminals on the speaker(s). Strip 3/8" / 1 cm of insulation of the end of each cable and twist the cable strands together tightly. Make sure there are no stray strands that could touch other cables or terminals as it can cause a short circuit.

Crimp spade plugs over the end of the cable or tin the ends with solder to provide a solid terminal. Connect the cable ends to the amplifier as shown in the diagram. Note, the amplifier's speaker terminals are internally bridged.


B² audio

SPEAKER WIRING DIAGRAM - SINGLE AMPLIFIER

ZERO.7R



STRAPPED CONTROL PANEL SETTING / SPEAKER WIRING



! SPEAKER IMPEDANCE 2 OHM - 16 OHM


Loads under what is specified will cause excessive heat & the amplifier will reach thermal at a faster rate & will eventually go into protect.

Strapped impedance load under 2 ohm is not warranted!

STRAPPED SPEAKER WIRING MASTER / SLAVE

ZERO.7R

Head unit



Linking or strapping makes 2 amplifiers work as a single amplifier. This configuration will near double the rated output power. Follow the instructions carefully as it can cause harm to your system if done incorrect.

To enable this function, let the master amplifier switch next to the phase knob stay in "OUTPUT MASTER". On the slave amplifier, this switch shall be in "INPUT SLAVE".

Run a RCA cable from the master amplifier's "RCA OUT". Connect the other end of the RCA to the slave amplifier's "RCA IN" located next to the "INPUT SLAVE" switch

⚠ SPEAKER IMPEDANCE 2 OHM - 16 OHM

Loads under what is specified will cause excessive heat & the amplifier will reach thermal at a faster rate & will eventually go into protect.

Strapped impedance load under 2 ohm is not warranted!

To link the master and slave amplifier speaker connection follow the steps below.

STEP 1.

Run the **POSITIVE (+)** speaker cable from the **MASTER** amplifier's speaker output to the **POSITIVE TERMINAL (+)** of the subwoofer.

STEP 2.

Run the **POSITIVE (+)** speaker cable from the **SLAVE** amplifier's speaker output to the **NEGATIVE TERMINAL (-)** of the subwoofer.


STEP 3.

Connect both amplifiers together by running a cable from **NEGATIVE** speaker output on **MASTER** amplifier to **NEGATIVE** speaker output on **SLAVE** amplifier. Use minimum 8 GA cable for connecting the amplifiers.

STRAPPED CONTROL PANELS SETTING STEPS

ZERO.7R

Head unit



Linking or strapping makes 2 amplifiers work as a single amplifier. This configuration will near double the rated output power. Follow the instructions carefully as it can cause harm to your system if done incorrect.

To enable this function, let the master amplifier switch next to the phase knob stay in "OUTPUT MASTER". On the slave amplifier, this switch shall be in "INPUT SLAVE".

Run a RCA cable from the master amplifier's "RCA OUT". Connect the other end of the RCA to the slave amplifier's "RCA IN" located next to the "INPUT SLAVE" switch

Speaker Impedance 2~ 16 ohms



SPEAKER IMPEDANCE 2 OHM - 16 OHM

Loads under what is specified will cause excessive heat & the amplifier will reach thermal at a faster rate & will eventually go into protect.

Strapped impedance load under 2 ohm is not warranted!

To link the master and slave amplifier RCA connection follow the steps below.

Keep in mind amplifiers needs to be switched off, linking the amplifiers when switched on may cause harm and can void your warranty!

STEP 1. Connect RCA from Head Unit / output source into **MASTER** amplifier RCA input.
If only one output is available, then use a Y-split to connect both L & R.

STEP 2. Locate the Master / Slave switch on the right side of the control panel on the **MASTER** amplifier.
Set the switch to **MASTER** position .


STEP 3. Connect a single RCA from the **RCA OUT** on the **MASTER** amplifier.

STEP 4. Locate the Master / Slave switch on the right side of the control panel on the **SLAVE** amplifier.
Set the switch to **SLAVE** position.

STEP 5. Connect the single RCA cable from the **MASTER** amplifier's **RCA OUT** to the **SLAVE** amplifier's single **RCA IN**.

CROSSOVER - BOOST SETTINGS

ZERO.7R



LOW PASS, BASS BOOST

The low pass crossover is 24 dB / oct. Setting it at 80 Hz will then have the signal cut off with 24 dB at 40 Hz (1 octave). To ensure accuracy for the individual crossover frequency the pot feature 41 clicks, each with a corresponding frequency. The same is valid for the bass boost settings, which also features 41 clicks.

CLICK SETTINGS FOR LPF - BASS BOOST

LPF	BOOST	LPF	BOOST	LPF	BOOST
1. 35 Hz	- 0,19 dB	15. 71,89 Hz	- 1,68 dB	29. 186,95 Hz	- 7,24 dB
2. 35,06 Hz	- 0,19 dB	16. 80,11 Hz	- 2,00 dB	30. 198,63 Hz	- 7,80 dB
3. 35,06 Hz	- 0,20 dB	17. 90,07 Hz	- 2,30 dB	31. 213,71 Hz	- 8,40 dB
4. 35,09 Hz	- 0,22 dB	18. 104,62 Hz	- 2,60 dB	32. 217,26 Hz	- 8,90 dB
5. 35,54 Hz	- 0,25 dB	19. 118,94 Hz	- 2,90 dB	33. 221,03 Hz	- 9,10 dB
6. 37,14 Hz	- 0,28 dB	20. 124,42 Hz	- 3,25 dB	34. 226,16 Hz	- 9,25 dB
7. 39,28 Hz	- 0,31 dB	21. 129,21 Hz	- 3,60 dB	35. 230,24 Hz	- 9,45 dB
8. 41,43 Hz	- 0,34 dB	22. 133,87 Hz	- 4,00 dB	36. 234,69 Hz	- 9,53 dB
9. 44,12 Hz	- 0,41 dB	23. 138,86 Hz	- 4,40 dB	37. 239,83 Hz	- 9,62 dB
10. 47,29 Hz	- 0,50 dB	24. 145,19 Hz	- 4,85 dB	38. 244,93 Hz	- 9,62 dB
11. 50,69 Hz	- 0,58 dB	25. 151,30 Hz	- 5,13 dB	39. 247,92 Hz	- 9,76 dB
12. 54,87 Hz	- 0,82 dB	26. 159,47 Hz	- 5,90 dB	40. 252,53 Hz	- 9,81 dB
13. 59,86 Hz	- 1,10 dB	27. 167,89 Hz	- 6,20 dB	41. 252,61 Hz	- 9,82 dB
14. 65,34 Hz	- 1,38 dB	28. 177,36 Hz	- 6,45 dB		

B² audio

TROUBLESHOOTING

The protection circuits of the amplifier prevents severe damages from faulty conditions & improper use. The protection indicator will switch on due to short circuit connection & speaker overload, thus the amplifier will be turned off. Prior to inspecting the occurred problem, turn all levels down & all power off, then carefully check the installation for wiring mistakes, shorts or faulty ground (GND). If the amplifier shuts down due to excessive heat, the protection indicator will light up; please allow time for the unit to be cooled off. Before removing your amplifier, refer to the list below and follow the suggested procedures step by step. If not at ease, contact an authorized installer which can assist you.

AMPLIFIER DOESN'T TURN ON

- Measure voltage on the +12V terminal.
- Ensure that the remote terminal has min. 13.8 V DC remote connection.
- Recheck the ground (GND) connection. Inspect the in-line fuses.
- Check the protection LED is not on.

PROTECTION LED IS LIT ONCE THE AMPLIFIER IS TURNED ON

- Check shorts on speaker wires & the connected load / impedance. Check power cables & GND.
- Disconnect the speaker cables and reset the amplifier.
- High / Low voltage, operation voltage is 9 V ~ 16 V+. Voltages below / beyond this will cause the amplifier to go into protect.

FUSE BLOWING

- Measure the speaker impedance & that it is in accordance with the configuration.
- Inspect the power cable for shorts along with vehicle chassis.

OVERHEATING

- Measure the speaker impedance & that it is in accordance with the configuration.
- Check speaker shorts.
- Ensure airflow around the amplifier is sufficient & that the amplifier is not installed in areas of excessive vibration & upside down!

AUDIO OUTPUT INSUFFICIENT - DISTORTED SOUND

- Ensure that the gain settings on the amplifier is matched with the output level of the head unit.
- Adjust the head unit volume.
- Check speaker shorts.
- Adjust the crossover frequencies in accordance with the setup.
- If no output at all, check the RCA connections & the cable itself.

TURN ON THUMP

- Disconnect the signal input to the amplifier, then turn it on and off.
 - a) If the noise is cancelled, then connect a delay turn on module on the REM wire running from the source unit to the amplifier.
 - b) Use another 12V source for REM lead to the amplifier. If the noise is cancelled, use a relay to isolate the amplifier from the turn on thump.

HIGH HISS-ENGINE NOISE IN SPEAKERS

- Ensure that all signal transferring wires (RCA, speaker cables etc) are kept separately / away from the power and the ground wires.
- Bypass all electrical components between the Head unit and the amplifier.
Connect the Head unit directly to the amplifier's input. If the noise is eliminated, the unit bypassed is the one causing the noise.
- Remove the existing ground wires for all electrical components installed. Ensure that the point of ground is 100% metal which has been grinded free of rust, paint etc.
- Replace the ground cable from the OEM battery / alternator and ensure it is grounded accordingly.
- Test the battery and alternator load (can be carried out by a professional).
Ensure that the vehicle's electrical system is in a good condition, this includes distributor, alternator, spark plugs / wires, voltage regulators etc.

B² audio

